

## Bjelin Oak skirting board

Bjelin's solid oak skirtings, made from FSC-certified wood, are the perfect choice for your floors.

They effectively conceal the joint between the floor and the wall while protecting the wall. Untreated skirtings can easily be finished to match the floor's shade.



General properties	
Surface finish	Lacquered
Name	Skirting board
Wood type	Oak
Height (mm)	60
Length (mm)	2200
Width (mm)	16

### INSTALLATION

#### How to install an oak floor skirting:

##### 1. Measure and cut

Measure the wall length and cut the skirting to size.  
Use a miter saw for precise cuts, especially at corners.

##### 2. Prepare the surface

Ensure the area where the skirting will be installed is clean.

##### 3. Attach the skirting

Secure the skirting to the wall using adhesive or nails. If using nails, pre-drill holes to prevent splitting the wood.

##### 4. Finishing touches

Fill any nail holes with wood filler and clean off any excess adhesive.