

Repair Kit | User guide

Excellent for repairing chips, scratches and damage in flooring.

For repairing chips, scratches and damage in flooring. Suitable for Bjelin Woodura Flooring, Bjelin Rigid Core, lacquered and oiled wood flooring, parquet, laminate, click vinyl, cork, vinyl flooring and linoleum – not for use in wet rooms.

CONTENTS

- 7 hard wax sticks – colours: 433, 591, 600, 561, 564, 506 and 556
- 1 battery-powered melting knife
- 1 plastic scraper
- 1 sanding pad

MELTING TOOL

The melting knife is heated by switching the slider to the “ON” position. Press and hold the button until the desired temperature is reached. The red indicator light will illuminate while the tool is heating.

Powered by 2 AA batteries (not included).

WARNING

The metal parts of the melting knife become extremely hot during use. Keep out of reach of children. Do not use on flammable materials.

STORAGE

The hard wax has an unlimited shelf life. Store in a dry place at room temperature. Avoid direct sunlight and open flames.

INSTRUCTIONS FOR USE

1. Clean the damaged area thoroughly so it is free from dirt, oil, wax, grease, etc.
2. Select a wax stick that closely matches the floor colour or knot. Melt a small amount into the damaged area using the melting knife. If needed, mix colours to achieve the correct shade.
3. Apply slightly more wax than needed to fill the damage (overfill).
4. Allow the wax to cool slightly, then remove excess using the plastic scraper.
5. After a few minutes, lightly sand the repaired area using the sanding pad.
6. For a more precise match, recreate the original grain pattern using a sharp object (e.g. a knife or needle), then fill with the desired colour (see step 2).
7. Any excess wax around the repair can be removed with a cloth and a small amount of acetone.
8. If you are not satisfied with the result, reheat the wax, remove it, and start again.
9. Tip: When repairing wood floors, recreating natural knots can help achieve a more seamless finish.